

# Einrichten vom W-Lan beim ARCH Linux Default Image

## Quelle Wifi/Wlan Config

- einloggen als root z.b. `ssh root@<pikvm-ip-adresse>`
- Filesystem ReadWrite einstellen (rw)
- W-lan Service einschalten „`systemctl enable netctl-auto@wlan0.service`“
- W-LAN per GUI oder CLI konfigurieren
  - `wifi-menu -o #GUI`
  - `wpa_passphrase wifiname this_is_my_great_and_secure_key_1234567890 #CLI WPA-Key`
  - `nano /etc/netctl/wlan0-wifiname #CLI Konfigurations file`

## Login & filesystem RW

```
ssh root@pikvm
rw
```

## GUI

### TIPP

[ The -o makes sure that the WiFi passphrase is stored encrypted. ]

```
wifi-menu -o
```

From:  
<https://skync.webnmail.de/> - [quad.logout.de](https://quad.logout.de)

Permanent link:  
<https://skync.webnmail.de/pikvm:wlan?rev=1603272369>

Last update: **2020/10/21 09:26**

